

User Manual

ECU-P1524PE HSR/PRP Module

ADVANTECH

Enabling an Intelligent Planet

Copyright

The documentation and the software included with this product are copyrighted 2017 by Advantech Co., Ltd. All rights are reserved. Advantech Co., Ltd. reserves the right to make improvements in the products described in this manual at any time without notice. No part of this manual may be reproduced, copied, translated or transmitted in any form or by any means without the prior written permission of Advantech Co., Ltd. Information provided in this manual is intended to be accurate and reliable. However, Advantech Co., Ltd. assumes no responsibility for its use, nor for any infringements of the rights of third parties, which may result from its use.

Acknowledgements

Microsoft Windows and MS-DOS are registered trademarks of Microsoft Corp. All other product names or trademarks are properties of their respective owners.

Product Warranty (2 years)

Advantech warrants to you, the original purchaser, that each of its products will be free from defects in materials and workmanship for two years from the date of purchase.

This warranty does not apply to any products which have been repaired or altered by persons other than repair personnel authorized by Advantech, or which have been subject to misuse, abuse, accident or improper installation. Advantech assumes no liability under the terms of this warranty as a consequence of such events.

Because of Advantech's high quality-control standards and rigorous testing, most of our customers never need to use our repair service. If an Advantech product is defective, it will be repaired or replaced at no charge during the warranty period. For out-of-warranty repairs, you will be billed according to the cost of replacement materials, service time and freight. Please consult your dealer for more details.

If you think you have a defective product, follow these steps:

1. Collect all the information about the problem encountered. (For example, CPU speed, Advantech products used, other hardware and software used, etc.) Note anything abnormal and list any onscreen messages you get when the problem occurs.
2. Call your dealer and describe the problem. Please have your manual, product, and any helpful information readily available.
3. If your product is diagnosed as defective, obtain an RMA (return merchandise authorization) number from your dealer. This allows us to process your return more quickly.
4. Carefully pack the defective product, a fully-completed Repair and Replacement Order Card and a photocopy proof of purchase date (such as your sales receipt) in a shippable container. A product returned without proof of the purchase date is not eligible for warranty service.
5. Write the RMA number visibly on the outside of the package and ship it prepaid to your dealer.

Product Warranty (2 years)

CE

This product has passed the CE test for environmental specifications. Test conditions for passing included the equipment being operated within an industrial enclosure. In order to protect the product from being damaged by ESD (Electrostatic Discharge) and EMI leakage, we strongly recommend the use of CE-compliant industrial enclosure products.

FCC Class A

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

Technical Support and Assistance

1. Visit the Advantech web site at www.advantech.com/support where you can find the latest information about the product.
2. Contact your distributor, sales representative, or Advantech's customer service center for technical support if you need additional assistance. Please have the following information ready before you call:
 - Product name and serial number
 - Description of your peripheral attachments
 - Description of your software (OS, version, application software, etc.)
 - A complete description of the problem
 - The exact wording of any error messages

Safety Instructions

1. Read these safety instructions carefully.
2. Keep this User Manual for later reference.
3. Disconnect this equipment from any AC outlet before cleaning. Use a damp cloth. Do not use liquid or spray detergents for cleaning.
4. For plug-in equipment, the power outlet socket must be located near the equipment and must be easily accessible.
5. Keep this equipment away from humidity.
6. Put this equipment on a reliable surface during installation. Dropping it or letting it fall may cause damage.
7. The openings on the enclosure are for air convection. Protect the equipment from overheating. **DO NOT COVER THE OPENINGS.**
8. Make sure the voltage of the power source is correct before connecting the equipment to the power outlet.
9. Position the power cord so that people cannot step on it. Do not place anything over the power cord.
10. All cautions and warnings on the equipment should be noted.
11. If the equipment is not used for a long time, disconnect it from the power source to avoid damage by transient overvoltage.
12. Never pour any liquid into an opening. This may cause fire or electrical shock.
13. Never open the equipment. For safety reasons, the equipment should be opened only by qualified service personnel.
14. If one of the following situations arises, get the equipment checked by service personnel:
 - The power cord or plug is damaged.
 - Liquid has penetrated into the equipment.
 - The equipment has been exposed to moisture.
 - The equipment does not work well, or you cannot get it to work according to the user's manual.
 - The equipment has been dropped and damaged.
 - The equipment has obvious signs of breakage.
15. **DO NOT LEAVE THIS EQUIPMENT IN AN ENVIRONMENT WHERE THE STORAGE TEMPERATURE MAY GO BELOW -20° C (-4° F) OR ABOVE 60° C (140° F). THIS COULD DAMAGE THE EQUIPMENT. THE EQUIPMENT SHOULD BE IN A CONTROLLED ENVIRONMENT.**

Contents

Chapter 1	Introduction.....	1
	Figure 1.1 ECU-P1524PE.....	2
1.1	The HSR/PRP Advantage.....	2
1.2	The SFP Advantage.....	3
1.3	Hardware Specification	3
	Table 1.1: Basic Specification	3
1.4	Appearance.....	3
1.4.1	Connectors Assignments.....	3
	Figure 1.2 Panel for ECU-P1524PE	3
	Table 1.2: Connectors Assignments.....	4
1.4.2	LED Indicators	4
	Table 1.3: LED Indicators	4
1.5	Package Checklist.....	4
1.6	Dimensions	5
	Figure 1.3 Dimension for ECU-P1524PE	5
1.7	Function Block.....	5
1.8	Selection Table	6
Chapter 2	Hardware Installation	7
2.1	Installing ECU-P1524PE	8
	Figure 2.1 Installing ECU-P1524PE	8
2.2	DIP Switch Setting	8
	Table 2.1: DIP Switch	8
2.3	Connection to a Fiber Optic Network	9
	Figure 2.2 Transceiver to the SFP slot	9
	Figure 2.3 Transceiver Inserted.....	10
	Figure 2.4 LC connected to the transceiver.....	10
	Figure 2.5 Remove LC connector.....	11
	Figure 2.6 Pull out from the slot.....	11
Chapter 3	Application	13
3.1	HSR Application	14
	Figure 3.1 HSR Network.....	14
3.2	PRP Application	14
	Figure 3.2 PRP Network	15

Chapter 1

Introduction

For smart substation now, keeping communication network smooth and reliable is rigorous and important. The concept “Redundancy” becomes critical. The two redundant communication standard, High-availability Seamless Redundancy (HSR) and Parallel Redundancy Protocol (PRP) , can provide seamless failover from a single point of failure. These two unified standard are necessary for communication networks in real-time substation automation application.

HSR and PRP protocols are technologies under IEC 62439-3 Clause 5/Clause 4.

Advantech ECU-P1524PE is a PCIe expansion card with HSR/PRP protocols function, can be inserted into Power & Energy Automation Computer (UNO-4673A/4683, ECU-4784)’s expansion slot to constitute a HSR/PRP switch in substation network for system seamless switching.

Advantech ECU-P1524PE is also equipped with two Intel i210 Gigabit LAN Network controllers, which are compliant with IEEE802.3u 1000 Base-X SFP Interface. LED indicators on the front panel can show its Link and Active status. These LAN controllers use PCIe resource, the bandwidth or throughput may be restricted by the PCIe bandwidth.



Figure 1.1 ECU-P1524PE

1.1 The HSR/PRP Advantage

High-availability Seamless Redundancy (HSR) is defined in IEC 62439-3 Clause 5 Standard, which provides zero-loss redundancy, zero-time recovery.

Parallel Redundancy Protocol (PRP) is IEC 62439-3 Clause 4 standard, which provides Zero downtime, no single point of failure, no package loss.

IEC-62439-3 PRP/HSR (IEC-61850 edition 2) protocols is prepare for high-availability networks. Redundancy for critical communication networks in real-time substation automation applications. Any device can be replaced/disconnected without breaking network connectivity; Zero-time recovery advantage over Rapid Spanning Tree Protocol (RSTP) and variants. IEC 62439-3PRP/HSR support IEEE1588 PTP compatible with IEEE 802.3Ethernet technology.

1.2 The SFP Advantage

The ECU-P1524PE's four SFP fiber slots provide a lot of flexibility when planning and implementing a network. The slots can accept any SFP-type fiber transceivers and these transceivers are designed for transmitting over distances of either 500m (multi-mode), 10km, 30km, 50km, 70km or 110km (single-mode) – and the slots support SFP transceivers for WDM single-fiber transmissions. This means that you can easily change the transmission mode and distance of the switch by simply pulling out the SFP transceiver and plugging in a different one. The SFP transceivers are hotswappable and plug-and-play! Also, the fact that the switch has four of these slots, means that the network manager can, for example, have one 10km transceiver in one slot and one 110km in the other.

1.3 Hardware Specification

Table 1.1: Basic Specification

Connector	120-pin connector for UNO- 4673A/4683/ECU-4784
BUS Interface	PCI Express (Not-Universal Interface)
Power Consumption	5V \pm 5% @ 1000mA typical; 5V \pm 5% @ 1300mA max; 3.3V \pm 5% @ 600mA typical; 3.3V \pm 5% @ 1300mA max;
Ethernet	2 x 1000 Base-X SFP Interface
	DIP Switch for protocol mode selection
HSR/PRP	2 x 1000 Base-X SFP Interface (ECU-P1524PE-GAE) 2 x 100 Base-FX SFP Interface (ECU-P1524PE-AE) 1 x 10/100/1000 Base-T(InterLink)
LED	5x Link/ ACT on UNO- 4673A/4683/ECU-4784front panel
Operating Temperature	-25~ 70°C (-13 ~ 158°F)
Storage Temperature	-40~85°C
Operating Humidity	5 ~ 95% RH non-condensing
Storage Humidity	5 ~ 95% RH non-condensing

1.4 Appearance

1.4.1 Connectors Assignments




Figure 1.2 Panel for ECU-P1524PE

Table 1.2: Connectors Assignments

Name	Function	Interface
LAN1	Ethernet	1000M Base-X SFP Interface
LAN2	Ethernet	1000M Base-X SFP Interface
HSR/PRP A	RedBox A	100M Base-FX SFP Interface (ECU-P1524PE-AE) 1000M Base-X SFP Interface (ECU-P1524PE-GAE)
HSR/PRP B	RedBox B	100M Base-FX SFP Interface (ECU-P1524PE-AE) 1000M Base-X SFP Interface (ECU-P1524PE-GAE)
InterLink	RedboxInter-Link	10/100/1000 Mbps Base-T

1.4.2 LED Indicators

There are few LEDs display the work status and network status located on the front panel of Power & Energy Automation Computer, each of them has its own specific meaning shown as below.

Table 1.3: LED Indicators

LED No.	LED Name	Color	Description
1	Link	White	Lighting, LAN1 is linked
2	Act	White	Blinking, Ethernet data being transmitted
3	Link	White	Lighting, LAN2 is linked
4	Act	White	Blinking, Ethernet data being transmitted
5	Link	White	Lighting, ECU-P1524 card insert into ECU-4784
6	Act	White	Blinking, Data transmitted between ECU-P1524 and ECU-4784
7	Link	White	Lighting, HSR/PRP_port A is linked
8	Act	White	Blinking, HSR/PRP_port A data transmitted
9	Link	White	Lighting, HSR/PRP_port B is linked
10	Act	White	Blinking, HSR/PRP_port B data transmitted
11	Link	White	Lighting, InterLink port is linked
12	Act	White	Blinking, InterLink port data being transmitted
13	HSR	White	Lighting, HSR function is on
14	PRP	White	Lighting, PRP function is on
15	100M	White	Lighting, HSR/PRP is 100M Base-FX SFP Interface
16	1000M	White	Lighting, HSR/PRP is 1000M Base-X SFP Interface

1.5 Package Checklist

The expansion module is shipped with the following items:

- ECU-P1524PE expansion module
- ROHS Notice (printed)
- Startup Manual (printed)

1.6 Dimensions





Figure 1.3 Dimension for ECU-P1524PE

1.7 Function Block



To support Redundancy box (Redbox) in a device at least three port, Port_A and Port_B for HSR/PRP protocol, InterLink port for Normal network.

Power & Energy Automation Computer (UNO-4673A/4683, ECU-4784) can be attached to the HSR/PRP network as an End Node without extra Ethernet switch or cable.

1.8 Selection Table

Advantech offers a complete set of products to support the ECU-P1524PE. These Products include:

ECU-P1524PE

Part Number	Description
ECU-P1524PE-GAE	2-port SFP Gigabit Base-X Ethernet Card with HSR/PRP
ECU-P1524PE-AE	2-port 100Mbps Base-FX Ethernet Card with HSR/PRP

Platform

ECU-4784 Series
ECU-4673A Series
ECU-4683 Series

SFP Module

Part Number	Description
SFP-FXM/LC	100Base-FX Multi-mode SFP module
SFP-FXS/LC-30E	100Base-FX Single-mode SFP module
SFP-GSX/LC	1000Base-SX Multi-mode SFP module
SFP-GLX/LC-10E	1000Base-LX Single-mode SFP module (10 km)
SFP-GLX/LC-20E	1000Base-LX Single-mode SFP module (20 km)
SFP-GLX/LC-40E	1000Base-LX Single-mode SFP module (40 km)
SFP-GXD/LC-50E	1000Base-XD Single-mode SFP module (50 km)
SFP-GZX/LC-70E	1000Base-ZX Single-mode SFP module (70 km)
SFP-GTX/RJ45	1000Base RJ45 SFP module

Chapter 2

Hardware Installation

2.1 Installing ECU-P1524PE

The ECU-P1524PE is an expansion card for the UNO-4673A, 83 and ECU-4784. The ECU-P1524PE can only be plugged into slot1 of the three expansion in UNO-4673A/4683, while both slot of ECU-4784 can support ECU-P1524PE. Follow these steps to integrate into the UNO-4673A/4683 and ECU-4784:

1. Unscrew the two screws on the blanking panel of slot then remove the blanking plate.
2. Plug the ECU-P1524PE into slot 1 of the UNO-4673A/4683 carefully and fix it by the two screws on the panel.




Figure 2.1 Installing ECU-P1524PE

2.2 DIP Switch Setting

ECU-P1524PE supports either HSR or PRP protocol; you can select HSR or PRP by hardware switch. The position meaning is shown below.


Table 2.1: DIP Switch

Picture	DIP Switch Setting (SW1)
	For HSR Mode: 1: "OFF" 2: "ON" 3: "any" 4: "any"
	For PRP Mode: 1: "ON" 2: "ON" 3: "any" 4: "any"
	For Normal Switch Mode: 1: "OFF" 2: "OFF" 3: "any" 4: "any"

2.3 Connection to a Fiber Optic Network

ECU-P1524PE has 4 SFP slots for connecting to the network segment with single-mode or multi-mode fiber. You can choose appropriate mini-GBIC transceivers to plug into the slot. Make sure the slot is aligned correctly and then slide the transceiver into the SFP slot until a click is heard. You can use proper multi-mode or single-mode fiber according to the inserted SFP transceiver. With fiber optic, it transmits speed up to 1000 Mbps and you can prevent noise interference from the system and transmission distance up to 110 km, depending on the mini-GBIC transceivers.

The small form-factor pluggable (SFP) is a compact optical transceiver used in optical communications for both telecommunication and data communications applications.

Note!  *The SFP port has the higher priority than copper port; if you insert the 1000M SFP transceiver into the SFP port which is connected to the remote device, the connection of the accompanying copper port will link down.*

If you insert the 100M SFP transceiver into the SFP port even without a fiber connection to the remote, the connection of the accompanying copper port will link down immediately.

To connect the transceiver and LC cable, please follow the steps shown below:

First, insert the transceiver into the SFP slot. Note that the location of the triangle indicates the bottom of the slot.




Figure 2.2 Transceiver to the SFP slot



Figure 2.3 Transceiver Inserted

Second, insert the fiber cable of LC connector into the transceiver.




Figure 2.4 LC connected to the transceiver

To remove the transceiver from the slot, please follow the steps shown below:
First, press the upper side of the LC connector to release from the transceiver and pull it out.




Figure 2.5 Remove LC connector

Second, push down the metal loop and pull the transceiver out by the plastic handle.




Figure 2.6 Pull out from the slot

Chapter 3

Application

3.1 HSR Application

Through the InterLink port of ECU-P1524PE, you can access to internet or communicate with non-HSR device like Ethernet switch and computer, which means you can expand network node or connect to other local network. ECU-4784 with an inserted ECU-P1524PE works as end node in HSR ring network.




Figure 3.1 HSR Network

3.2 PRP Application

Through the Interlink port of ECU-P1524PE, you can expand network node. The network node attached to ECU-P1524PE can communicate with any of end device in two local networks, but the device attached to Ethernet switch can communicate only with device in the same local network. For example, device A can communicate with any device in PRP network, but device B cannot communicate with device B.




Figure 3.2 PRP Network

www.advantech.com

Please verify specifications before quoting. This guide is intended for reference purposes only.

All product specifications are subject to change without notice.

No part of this publication may be reproduced in any form or by any means, electronic, photocopying, recording or otherwise, without prior written permission of the publisher.

All brand and product names are trademarks or registered trademarks of their respective companies.

© Advantech Co., Ltd. 2017