



G-4511-2G Series

Quick Start

Date 2013/06/06

Package Checklist

The package includes the following items:

- One G-4511-2G hardware module
- One Quick Start (this manual)
- One companion CD
- One RS-232 download cable (CA-0910)
- One 2G antenna
- One GPS antenna (only for G-4511P-2G, G-4511PD-2G)
- Screw Driver
- Two mounting screws
- Two L-type wall mount flat pieces

	G-4511
Casing	Metal
Dimensions	47 mm x 142 mm x 168 mm (W x L x H)
Installation	DIN-Rail and Wall mount

Related Documents and Software Utilities


Documents

- User Manual: G-4511-2G_User_Manual.pdf
- Quick Start: G-4511-2G_QuickStart.pdf
- CD: \napdos\G-4511-2G\Manual
- <http://ftp.icpdas.com/pub/cd/usbcd/napdos/G-4511-2G/manual>


MiniOS7 Utility

- [Http://ftp.icpdas.com/pub/cd/8000cd/napdos/minios7/utility/minios7_utility/](http://ftp.icpdas.com/pub/cd/8000cd/napdos/minios7/utility/minios7_utility/)

➤ Pin Assignments




➤ Dimensions (Unit: mm)



Unit : mm

➤ Installation

1. Install 2G Antenna.
2. Plug in the normal SIM card (Before apply the SIM card, confirm it is OK by mobile phone.)
3. Connect the DC.+VS and DC.GND to the power supply or Solar Panel.
4. Connect BAT.+VS and BAT.GND to the 12V Lead Acid Battery.









➤ Operation Mode Switch





Operation Mode Switch	
RUN	OS can execute autoexec.bat
	Flash can be read/write.
LRun	OS can execute autoexec.bat
	Flash is read only (lock).
INIT	OS can not execute autoexec.bat
	Flash can be read/write.

➤ Wire Connection


● Digital Input Wire Connection

Input Type	ON State DI value as 0	OFF State DI value as 1
Relay Contact		
TTL/CMOS Logic		
Open Collector		


● Digital Output Wire Connection

Input Type	ON State DO value as 1	OFF State DO value as 0
Drive Relay		
Resistance Load		

● Current Input Wire Connection


Input Type	
------------	--------------------------------------------------------------------------------------

- Relay Wire Connection



➤ Wake up from Sleep mode

1. When G-4511 was in sleep mode, you can connect the Pin “U2 DI” (MCU2 DI) to GND. to awaking G-4511 from sleep mode.
2. You will read “U2 DI” as 0, when you connect “U2 DI” to GND.



➤ Install MiniOS7 Utility


The installation software can be obtained from:

http://ftp.icpdas.com/pub/cd/8000cd/napdos/minios7/utility/minios7_utility/


➤ Launch MiniOS7 Utility



➤ Select connect G-4511 to Host PC




➤ Setup the COM Port parameter



Note: G-4511 default COM Port parameter 115200, 8, N, 1


➤ Download Demo into the G-4511

1. You can be obtained from the following location:
CD: \napdos\G-4511-2G\Software\Demo
[Http://ftp.icpdas.com/pub/cd/usbcd/napdos/G-4511-2G/software/demo](http://ftp.icpdas.com/pub/cd/usbcd/napdos/G-4511-2G/software/demo)
2. Click the “Look in” pull-down menu to the location of Demo.
3. Drag-and-drop the files from left hand window to right hand window.




➤ RUN the Demo

Step1.



Step2. Key in the command, “run”, to implement the execution file.



➤ Technical Support

1. ICP DAS Service : service@icpdas.com
2. G-4511 software Website:
<http://m2m.icpdas.com/g-4511.html>