



MODEL:
HYPER-BT

PICO-ITX SBC supports Intel® 22nm Atom™/Celeron® on-board SoC,
DDR3L, VGA/iDP, GbE, USB 3.0, SATA 3Gb/s,
HD Audio and RoHS

User Manual

Revision

Date	Version	Changes
14 July, 2017	1.03	Updated revision to V1.03
30 June, 2017	1.02	Updated BIOS spec on page 7
4 July, 2014	1.01	Updated supported memory specifications in Chapter 1.
25 June, 2014	1.00	Initial release

Copyright

COPYRIGHT NOTICE

The information in this document is subject to change without prior notice in order to improve reliability, design and function and does not represent a commitment on the part of the manufacturer.

In no event will the manufacturer be liable for direct, indirect, special, incidental, or consequential damages arising out of the use or inability to use the product or documentation, even if advised of the possibility of such damages.

This document contains proprietary information protected by copyright. All rights are reserved. No part of this manual may be reproduced by any mechanical, electronic, or other means in any form without prior written permission of the manufacturer.

TRADEMARKS

All registered trademarks and product names mentioned herein are used for identification purposes only and may be trademarks and/or registered trademarks of their respective owners.

Table of Contents

1 INTRODUCTION.....	1
1.1 INTRODUCTION.....	2
1.2 MODEL VARIATIONS	2
1.3 FEATURES.....	3
1.4 CONNECTORS	4
1.5 DIMENSIONS.....	5
1.6 DATA FLOW	6
1.7 TECHNICAL SPECIFICATIONS	7
2 UNPACKING	10
2.1 ANTI-STATIC PRECAUTIONS	11
2.2 UNPACKING PRECAUTIONS.....	11
2.3 PACKING LIST.....	12
2.4 OPTIONAL ITEMS	13
3 CONNECTORS	14
3.1 PERIPHERAL INTERFACE CONNECTORS.....	15
3.1.1 <i>HYPER-BT Layout</i>	15
3.1.2 <i>Peripheral Interface Connectors</i>	15
3.1.3 <i>External Interface Panel Connectors</i>	16
3.2 INTERNAL PERIPHERAL CONNECTORS	17
3.2.1 <i>AT/ATX Mode Select Switch</i>	17
3.2.2 <i>Audio Connector</i>	18
3.2.3 <i>Battery Connector</i>	18
3.2.4 <i>BIOS FW Connector</i>	19
3.2.5 <i>Buzzer Connector</i>	20
3.2.6 <i>Clear CMOS Button</i>	21
3.2.7 <i>CPU Fan Connector</i>	22
3.2.8 <i>DDR3L SO-DIMM Slot</i>	23
3.2.9 <i>Display Port Connector</i>	23
3.2.10 <i>EC FW Connector</i>	24

HYPER-BT

3.2.11 Front Panel Connector.....	25
3.2.12 LAN LED Connector.....	26
3.2.13 Power Button Connector.....	27
3.2.14 Reset Button Connector	28
3.2.15 RS-232 Serial Port Connector	29
3.2.16 SATA 3Gb/s Drive Connector	29
3.2.17 SATA Power Connector.....	30
3.2.18 USB Connector	31
3.3 EXTERNAL PERIPHERAL INTERFACE CONNECTOR PANEL	32
3.3.1 LAN Connector	32
3.3.2 Power Connector	33
3.3.3 USB Connectors.....	33
3.3.1 VGA Connector	34
4 INSTALLATION	36
4.1 ANTI-STATIC PRECAUTIONS	37
4.2 INSTALLATION CONSIDERATIONS.....	37
4.3 SO-DIMM INSTALLATION	39
4.4 INTERNAL PERIPHERAL DEVICE CONNECTIONS.....	40
4.4.1 Audio Kit Installation.....	40
4.4.2 SATA Drive Connection	41
4.4.3 Single RS-232 Cable	42
4.5 EXTERNAL PERIPHERAL INTERFACE CONNECTION	43
4.5.1 LAN Connection.....	43
4.5.2 USB Connection.....	44
4.5.3 VGA Monitor Connection	45
5 BIOS.....	47
5.1 INTRODUCTION.....	48
5.1.1 Starting Setup.....	48
5.1.2 Using Setup	48
5.1.3 Getting Help.....	49
5.1.4 Unable to Reboot after Configuration Changes	49
5.1.5 BIOS Menu Bar.....	49
5.2 MAIN.....	50

5.3 ADVANCED	51
5.3.1 ACPI Settings	52
5.3.2 IT8528 Super IO Configuration	53
5.3.2.1 Serial Port 1 Configuration	53
5.3.3 Hardware Monitor	54
5.3.3.1 Smart Fan Mode Configuration	55
5.3.4 RTC Wake Settings	58
5.3.5 Serial Port Console Redirection	59
5.3.5.1 Console Redirection Settings	60
5.3.6 CPU Configuration	63
5.3.7 IDE Configuration	64
5.3.8 USB Configuration	65
5.4 CHIPSET	66
5.4.1 North Bridge Configuration	67
5.4.1.1 Intel IGD Configuration	67
5.4.2 Southbridge Configuration	69
5.5 SECURITY	70
5.6 BOOT	71
5.7 EXIT	73
A REGULATORY COMPLIANCE	75
B PRODUCT DISPOSAL	77
C BIOS MENU OPTIONS	79
D TERMINOLOGY	82
E HAZARDOUS MATERIALS DISCLOSURE	87

List of Figures

Figure 1-1: HYPER-BT	2
Figure 1-2: Connectors	4
Figure 1-3: Dimensions (mm)	5
Figure 1-4: Data Flow Diagram	6
Figure 3-1: Connector and Jumper Locations (Front)	15
Figure 3-2: AT/ATX Mode Select Switch Location	18
Figure 3-3: Audio Connector Location	18
Figure 3-4: Battery Connector Location	19
Figure 3-5: BIOS FW Connector Location	20
Figure 3-6: Buzzer Connector Location	21
Figure 3-7: Clear CMOS Button Location	22
Figure 3-8: CPU Fan Connector Location	22
Figure 3-9: DDR3L SO-DIMM Slot Location	23
Figure 3-10: Display Port Connector Location	24
Figure 3-11: EC FW Connector Location	25
Figure 3-12: Front Panel Connector Location	26
Figure 3-13: LAN LED Connector Location	27
Figure 3-14: Power Button Connector Location	27
Figure 3-15: Reset Button Connector Location	28
Figure 3-16: RS-232 Serial Port Connector Location	29
Figure 3-17: SATA 3Gb/s Drive Connector Location	30
Figure 3-18: SATA Power Connector Location	30
Figure 3-19: USB Connector Location	31
Figure 3-20: External Peripheral Interface Connector	32
Figure 3-21: LAN Connector	32
Figure 3-22: VGA Connector	34
Figure 4-1: SO-DIMM Installation	39
Figure 4-2: Audio Kit Cable Connection	40
Figure 4-3: SATA Drive Cable Connection	41
Figure 4-4: Single RS-232 Cable Installation	42
Figure 4-5: LAN Connection	44

Figure 4-6: USB Connector45
Figure 4-7: VGA Connector46

List of Tables

Table 1-1: HYPER-BT Model Variations	2
Table 1-2: Technical Specifications	9
Table 3-1: Peripheral Interface Connectors	16
Table 3-2: Rear Panel Connectors	16
Table 3-3: AT/ATX Mode Select Switch Settings	17
Table 3-4: Audio Connector Pinouts	18
Table 3-5: Battery Connector Pinouts	19
Table 3-6: BIOS FW Connector Pinouts	20
Table 3-7: Buzzer Connector Pinouts	21
Table 3-8: Clear CMOS Button Settings	21
Table 3-9: CPU Fan Connector Pinouts	23
Table 3-10: Display Port Connector Pinouts	24
Table 3-11: EC FW Connector Pinouts	25
Table 3-12: Front Panel Connector Pinouts	26
Table 3-13: LAN LED Connector Pinouts	27
Table 3-14: Power Button Connector Pinouts	28
Table 3-15: Reset Button Connector Pinouts	28
Table 3-16: RS-232 Serial Port Connector Pinouts	29
Table 3-17: SATA Power Connector Pinouts	31
Table 3-18: USB Connector Pinouts	31
Table 3-19: LAN Pinouts	33
Table 3-20: Connector LEDs	33
Table 3-21: Power Connector Pinouts	33
Table 3-22: USB 2.0 & USB 3.0 Port Pinouts	34
Table 3-23: VGA Connector Pinouts	35
Table 5-1: BIOS Navigation Keys	49

List of BIOS Menus

BIOS Menu 1: Main	50
BIOS Menu 2: Advanced	51
BIOS Menu 3: ACPI Configuration	52
BIOS Menu 4: Super IO Configuration.....	53
BIOS Menu 5: Serial Port 1 Configuration Menu	53
BIOS Menu 6: Hardware Monitor.....	55
BIOS Menu 7: Smart Fan Mode Configuration	56
BIOS Menu 8: RTC Wake Settings	58
BIOS Menu 9: Serial Port Console Redirection	60
BIOS Menu 10: Console Redirection Settings.....	61
BIOS Menu 11: CPU Configuration	63
BIOS Menu 12: IDE Configuration.....	64
BIOS Menu 13: USB Configuration	65
BIOS Menu 14: Chipset	66
BIOS Menu 15: Northbridge Chipset Configuration.....	67
BIOS Menu 16: Integrated Graphics	68
BIOS Menu 17: Southbridge Chipset Configuration	69
BIOS Menu 18: Security	70
BIOS Menu 19: Boot	71
BIOS Menu 20:Exit.....	73

Chapter

1

Introduction

1.1 Introduction



Figure 1-1: HYPER-BT

The HYPER-BT PICO-ITX motherboard is an Intel® Atom™/Celeron® processor platform. It supports one 204-pin 1066/1333 MHz single-channel DDR3L SO-DIMM supports up to 8GB (J1900, N2930, E3845, E3827, E3826) or 4GB (N2807, E3825, E3815).

The HYPER-BT includes a VGA connector and an iDP connector. Expansion and I/O include one USB 2.0 connector and one USB 3.0 connector on the rear panel, two USB 2.0 connectors by pin header and one SATA 3Gb/s connector. Serial device connectivity is provided by one internal RS-232 connector. One RJ-45 Ethernet connector provides the system with smooth connections to an external LAN.

1.2 Model Variations

The model variations of the HYPER-BT Series are listed below.

Model No.	SoC
HYPER-BT-J19001	Intel® Celeron® quad-core J1900 (10W)
HYPER-BT-N29301	Intel® Celeron® quad-core N2930 (7.5W)
HYPER-BT-N28071	Intel® Celeron® dual-core N2807 (4.3W)
HYPER-BT-E38XX1	Intel® Atom™ E38XX

Table 1-1: HYPER-BT Model Variations

HYPER-BT

1.3 Features

Some of the HYPER-BT motherboard features are listed below:

- PICO-ITX SBC supports Intel® 22nm Atom™ or Celeron® on-board SoC
- 12V only single voltage design for AT/ATX power by DC power jack
- VGA and iDP support for dual display
- IEI One Key Recovery solution allows you to create rapid OS backup and recovery

1.4 Connectors

The connectors on the HYPER-BT are shown in the figure below.




Figure 1-2: Connectors

HYPER-BT

1.5 Dimensions

The dimensions of the board are listed below:




Figure 1-3: Dimensions (mm)

1.6 Data Flow

Figure 1-4 shows the data flow between the system chipset, the CPU and other components installed on the motherboard.




Figure 1-4: Data Flow Diagram

HYPER-BT

1.7 Technical Specifications

HYPER-BT technical specifications are listed below.

Specification	HYPER-BT
SoC	<p>Intel® Atom™ E3845 on-board SoC (1.91GHz, quad-core, 2MB cache, TDP=10W)</p> <p>Intel® Atom™ E3827 on-board SoC (1.75GHz, dual-core, 1MB cache, TDP=8W)</p> <p>Intel® Atom™ E3826 on-board SoC (1.46GHz, dual-core, 1MB cache, TDP=7W)</p> <p>Intel® Atom™ E3825 on-board SoC (1.33GHz, dual-core, 1MB cache, TDP=6W)</p> <p>Intel® Atom™ E3815 on-board SoC (1.46GHz, dual-core, 1MB cache, TDP=5W)</p> <p>Intel® Celeron® J1900 on-board SoC (2GHz, quad-core, 2MB cache, TDP=10W)</p> <p>Intel® Celeron® N2930 on-board SoC (1.83GHz, quad-core, 2MB cache, TDP=7.5W)</p> <p>Intel® Celeron® N2807 on-board SoC (1.58GHz, dual-core, 2MB cache, TDP=4.3W)</p>
BIOS	<p>AMI UEFI BIOS</p> <ul style="list-style-type: none"> ▪ Alxx BIOS version is for Bay Trail I model (CPU: E38xx) ▪ AMxx BIOS version is for Bay Trail M/D model (CPU: J1900/ N2930/N2807)
Memory	<p>One 204-pin 1066/1333 MHz single-channel DDR3L SO-DIMM supports up to 8GB (J1900, N2930, E3845, E3827, E3826) or 4GB (N2807, E3825, E3815)</p>
Graphics	<p>Intel® HD Graphics Gen 7 Engines with 4 execution units, supporting DX11.1 OpenGL 4.2 and OpenCL 1.2</p>

Specification	HYPER-BT
Display Output	Dual independent display 1 x VGA (up to 2560x1600@60Hz) 1 x iDP interface for HDMI, LVDS, VGA, DVI, DP (up to 3840x2160@60Hz)
Ethernet	LAN: Intel® I211-AT PCIe controller
EC	IT8587
Audio	Realtek ALC662 HD codec supports 5.1 channel
Watchdog Timer	Software programmable support 1~255 sec. system reset
I/O Interface	
Audio Connector	1 x Analog audio by 10-pin (2x5) header
Ethernet	One RJ-45 port
Serial Ports	1 x RS-232 (by pin header)
USB Ports	1 x USB 3.0 (on rear I/O) 3 x USB 2.0 (1 on rear I/O, 2 by pin header)
Front Panel	1 x 6-pin (1x6) wafer for power LED & HDD LED 1 x 2-pin (1x2) wafer for power button 1 x 2-pin (1x2) wafer for power reset button
LAN LED	1 x 2-pin (1x2) header
FAN	1 x 4-pin system fan connector
Storage	
Serial ATA	1 x SATA 3Gb/s with 5V SATA power connector
Environmental and Power Specifications	
Power Supply	12V DC power input only, AT/ATX supported 1 x External DC power jack
Power Consumption	+12V@1.35A (Intel® Celeron® J1900 CPU, 1 x 8GB 1333 MHz DDR3 memory)
Operating Temperature	-20°C ~ 60°C

HYPER-BT

Specification	HYPER-BT
Storage Temperature	-30°C ~ 70°C
Humidity	5% ~ 95%, non-condensing
Physical Specifications	
Dimensions	100 mm x 72 mm
Weight GW/NW	600 g / 250 g

Table 1-2: Technical Specifications

Chapter

2

Unpacking

HYPER-BT

2.1 Anti-static Precautions



WARNING!

Static electricity can destroy certain electronics. Make sure to follow the ESD precautions to prevent damage to the product, and injury to the user.

Make sure to adhere to the following guidelines:

- **Wear an anti-static wristband:** Wearing an anti-static wristband can prevent electrostatic discharge.
- **Self-grounding:** Touch a grounded conductor every few minutes to discharge any excess static buildup.
- **Use an anti-static pad:** When configuring any circuit board, place it on an anti-static mat.
- **Only handle the edges of the PCB:** Don't touch the surface of the motherboard. Hold the motherboard by the edges when handling.

2.2 Unpacking Precautions

When the HYPER-BT is unpacked, please do the following:

- Follow the antistatic guidelines above.
- Make sure the packing box is facing upwards when opening.
- Make sure all the packing list items are present.







2.3 Packing List




NOTE:

If any of the components listed in the checklist below are missing, do not proceed with the installation. Contact the IEI reseller or vendor the HYPER-BT was purchased from or contact an IEI sales representative directly by sending an email to sales@iei.com.tw.

The HYPER-BT is shipped with the following components:


Quantity	Item and Part Number	Image
1	1 x HYPER-BT single board computer with specific heat sink	
1	Audio cable (P/N: 32000-072100-RS)	
1	SATA with 5V output cable kit (P/N: 32801-000201-100-RS)	
1	RS-232 cable (P/N: 32200-000049-RS)	
1	Utility CD	
1	One Key Recovery CD	

HYPER-BT

1	Quick Installation Guide	
---	--------------------------	---

2.4 Optional Items

The following are optional components which may be separately purchased:

Item and Part Number	Image
Dual-port USB cable without bracket (P/N: 32000-070301-RS)	

Chapter

3

Connectors

HYPER-BT

3.1 Peripheral Interface Connectors

This chapter details all the jumpers and connectors.

3.1.1 HYPER-BT Layout

The figures below show all the connectors and jumpers.




Figure 3-1: Connector and Jumper Locations (Front)

3.1.2 Peripheral Interface Connectors

The table below lists all the connectors on the board.

Connector	Type	Label
AT/ATX mode select switch	switch	J_ATX_AT1
Audio connector	10-pin header	AUDIO1
Battery connector	2-pin wafer	BAT1
BIOS FW connector	6-pin wafer	JSPI1

Buzzer connector	2-pin wafer	SP1
Clear CMOS button	button	J_CMOS1
CPU fan connector	4-pin wafer	CPU_FAN1
DDR3L SO-DIMM slot	DDR3L SO-DIMM slot	DIMM1
Display port connector	20-pin header	DP1
EC FW connector	2-pin wafer	JP3
Front panel connector	6-pin wafer	CN5
LAN LED connector	2-pin header	JP2
Power button connector	2-pin wafer	PWR_BTN1
Reset button connector	2-pin wafer	RST_BTN1
RS-232 serial port connector	10-pin header	COM1
SATA 3Gb/s drive connector	7-pin SATA connector	SATA1
SATA power connector	2-pin wafer	SATA_PWR1
USB 2.0 connector	8-pin header	USB_CAM1

Table 3-1: Peripheral Interface Connectors

3.1.3 External Interface Panel Connectors

The table below lists the connectors on the external I/O panel.

Connector	Type	Label
12V DC IN Connector	DC power jack	J1
LAN connector	RJ-45	LAN1
USB 2.0 & USB 3.0 connector	USB 2.0 & USB 3.0	CN2
VGA Connector	15-pin female	VGA1

Table 3-2: Rear Panel Connectors

HYPER-BT

3.2 Internal Peripheral Connectors

The section describes all of the connectors on the HYPER-BT.

3.2.1 AT/ATX Mode Select Switch

CN Label:	J_ATX_AT1
CN Type:	switch
CN Location:	See Figure 3-2
CN Settings:	See Table 3-3

The AT/ATX mode select switch specifies the systems power mode as AT or ATX. AT/ATX mode select switch settings are shown in **Table 3-3**.

Setting	Description
Short A-B	AT Mode
Short B-C	ATX Mode

Table 3-3: AT/ATX Mode Select Switch Settings

The location of the AT/ATX mode select switch is shown in **Figure 3-2** below.




Figure 3-2: AT/ATX Mode Select Switch Location

3.2.2 Audio Connector

- CN Label: **AUDIO1**
- CN Type: 10-pin header
- CN Location: See **Figure 3-3**
- CN Pinouts: See **Table 3-4**

The audio connector is connected to external audio devices including speakers and microphones for the input and output of audio signals to and from the system.




Figure 3-3: Audio Connector Location

Pin	Description	Pin	Description
1	LINE_OUTR	2	LINEIN_R
3	Analog_GND	4	Analog_GND
5	LINE_OUTL	6	LINEIN_L
7	Analog_GND	8	Analog_GND
9	LMIC1-R	10	LMIC1-L

Table 3-4: Audio Connector Pinouts

3.2.3 Battery Connector

- CN Label: **BAT1**

HYPER-BT

- CN Type: 2-pin wafer
- CN Location: See **Figure 3-4**
- CN Pinouts: See **Table 3-5**

The battery connector is connected to the system battery. The battery provides power to the system clock to retain the time when power is turned off.




Figure 3-4: Battery Connector Location

Pin	Description	Pin	Description
1	VBATT	2	GND

Table 3-5: Battery Connector Pinouts

3.2.4 BIOS FW Connector

- CN Label: JSPII
- CN Type: 6-pin wafer
- CN Location: See **Figure 3-5**
- CN Pinouts: See **Table 3-6**

The BIOS FW connector is used for programming the BIOS.




Figure 3-5: BIOS FW Connector Location

Pin	Description	Pin	Description
1	+V1.8M_SPI_CON	2	SPI_CS
3	SPI_SO_SW	4	SPI_CLK_SW
5	SPI_SI_SW	6	GND

Table 3-6: BIOS FW Connector Pinouts

3.2.5 Buzzer Connector

- CN Label: **SP1**
- CN Type: 2-pin wafer
- CN Location: See **Figure 3-6**
- CN Pinouts: See **Table 3-7**

The buzzer connector is connected to the buzzer.

HYPER-BT




Figure 3-6: Buzzer Connector Location

Pin	Description	Pin	Description
1	Buzzer +	2	Buzzer -

Table 3-7: Buzzer Connector Pinouts

3.2.6 Clear CMOS Button

CN Label:	J_CMOS 1
CN Type:	button
CN Location:	See Figure 3-7
CN Settings:	See Table 3-8

If the HYPER-BT fails to boot due to improper BIOS settings, use the button to clear the CMOS data and reset the system BIOS information.

The clear CMOS button settings are shown in **Table 3-8**.

Setting	Description	
Open	Normal Operation	Default
Push	Clear CMOS Setup	

Table 3-8: Clear CMOS Button Settings

The location of the clear CMOS button is shown in **Figure 3-7**.




Figure 3-7: Clear CMOS Button Location

3.2.7 CPU Fan Connector

- CN Label: CPU_FAN1
- CN Type: 4-pin wafer
- CN Location: See **Figure 3-8**
- CN Pinouts: See **Table 3-9**

The fan connector attaches to a cooling fan.




Figure 3-8: CPU Fan Connector Location

Pin	Description	Pin	Description
1	GND	2	+V12_FAN

HYPER-BT

Pin	Description	Pin	Description
3	FANIO1_EC	4	FANOUT1_EC

Table 3-9: CPU Fan Connector Pinouts

3.2.8 DDR3L SO-DIMM Slot

CN Label: DIMM1
 CN Type: DDR3L SO-DIMM slot
 CN Location: See **Figure 3-9**

The DDR3L SO-DIMM slot is for DDR3L SO-DIMM memory module.




Figure 3-9: DDR3L SO-DIMM Slot Location

3.2.9 Display Port Connector

CN Label: DP1
 CN Type: 20-pin box header
 CN Location: See **Figure 3-10**
 CN Pinouts: See **Table 3-10**

The disport port connector provides flexible display function that supports VGA, DVI, LVDS, HDMI and DisplayPort via the disport port convert board.




Figure 3-10: Display Port Connector Location

Pin	Description	Pin	Description
1	DDI1_HPDI#	2	DPD_AUX_CTRL_P2
3	GND	4	DPD_AUX_CTRL_N2
5	AUX_CTRL_DET_D	6	GND
7	GND	8	DPD_OB_LANE2_P
9	DPD_OB_LANE3_P	10	DPD_OB_LANE2_N
11	DPD_OB_LANE3_N	12	GND
13	GND	14	DPD_OB_LANE0_P
15	DPD_OB_LANE1_P	16	DPD_OB_LANE0_N
17	DPD_OB_LANE1_N	18	GND
19	VCC	20	NC

Table 3-10: Display Port Connector Pinouts

3.2.10 EC FW Connector

- CN Label: JP3
- CN Type: 2-pin header
- CN Location: See **Figure 3-11**
- CN Pinouts: See **Table 3-11**

The EC FW connector is used for programming the EC.

HYPER-BT




Figure 3-11: EC FW Connector Location

Pin	Description	Pin	Description
1	SMB_CLK_FW	2	SMB_DATA_FW

Table 3-11: EC FW Connector Pinouts

3.2.11 Front Panel Connector

- CN Label: CN5
- CN Type: 6-pin wafer
- CN Location: See **Figure 3-12**
- CN Pinouts: See **Table 3-12**

The front panel connector connects to the indicator LEDs on the system front panel.




Figure 3-12: Front Panel Connector Location

Pin	Description	Pin	Description
1	+V5S	2	GND
3	PWR_LED+	4	PWR_LED-
5	HDD_LED+	6	HDD_LED-

Table 3-12: Front Panel Connector Pinouts

3.2.12 LAN LED Connector

- CN Label: JP2
- CN Type: 2-pin header
- CN Location: See **Figure 3-13**
- CN Pinouts: See **Table 3-13**

The LAN LED connectors connect to the LAN link LEDs on the system.

HYPER-BT




Figure 3-13: LAN LED Connector Location

Pin	Description	Pin	Description
1	VCC	2	L1_LINK_ACT-

Table 3-13: LAN LED Connector Pinouts

3.2.13 Power Button Connector

- CN Label: PWR_BTN1
- CN Type: 2-pin wafer
- CN Location: See **Figure 3-14**
- CN Pinouts: See **Table 3-14**

The power button connector is connected to a power switch on the system chassis to enable users to turn the system on and off.




Figure 3-14: Power Button Connector Location

Pin	Description
1	PWRBTN_SW#
2	GND

Table 3-14: Power Button Connector Pinouts

3.2.14 Reset Button Connector

- CN Label: RST_BTN1
- CN Type: 2-pin wafer
- CN Location: See **Figure 3-15**
- CN Pinouts: See **Table 3-15**

The reset button connector is connected to a reset switch on the system chassis to enable users to reboot the system when the system is turned on.




Figure 3-15: Reset Button Connector Location

Pin	Description
1	PM_SYSRST_R#
2	GND

Table 3-15: Reset Button Connector Pinouts

HYPER-BT

3.2.15 RS-232 Serial Port Connector

- CN Label: COM1
- CN Type: 10-pin header
- CN Location: See **Figure 3-16**
- CN Pinouts: See **Table 3-16**

The serial connector provides RS-232 connection.




Figure 3-16: RS-232 Serial Port Connector Location

Pin	Description	Pin	Description
1	-NDCD1	2	-NDSR1
3	NSIN1	4	-NRTS1
5	NSOUT1	6	-NCTS1
7	-NDTR1	8	-XRI1
9	GND	10	GND

Table 3-16: RS-232 Serial Port Connector Pinouts

3.2.16 SATA 3Gb/s Drive Connector

- CN Label: **SATA1**
- CN Type: 7-pin SATA connector
- CN Location: See **Figure 3-17**

The SATA 3Gb/s drive connector is connected to a SATA 3Gb/s drive. The SATA 3Gb/s drive transfers data at speeds as high as 3Gb/s.




Figure 3-17: SATA 3Gb/s Drive Connector Location

3.2.17 SATA Power Connector

- CN Label: **SATA_PWR1**
- CN Type: 2-pin wafer
- CN Location: See **Figure 3-18**
- CN Pinouts: See **Table 3-17**

The SATA power connector provides +5V power output to the SATA connector.




Figure 3-18: SATA Power Connector Location

Pin	Description
1	+5V

HYPER-BT

Pin	Description
2	GND

Table 3-17: SATA Power Connector Pinouts

3.2.18 USB Connector

- CN Label: **USB2_CAM1**
- CN Type: 8-pin header
- CN Location: See **Figure 3-19**
- CN Pinouts: See **Table 3-18**

The USB connector provides two USB 2.0 ports by dual-port USB cable.




Figure 3-19: USB Connector Location

Pin	Description	Pin	Description
1	VCC	2	GND
3	DATA2_N	4	DATA3_P
5	DATA2_P	6	DATA3_N
7	GND	8	VCC

Table 3-18: USB Connector Pinouts

3.3 External Peripheral Interface Connector Panel

Figure 3-20 shows the HYPER-BT external peripheral interface connector (EPIC) panel. The EPIC panel consists of the following:

- 1 x LAN connector
- 1 x Power connector
- 1 x USB 2.0 & USB 3.0 connector
- 1 x VGA connector




Figure 3-20: External Peripheral Interface Connector

3.3.1 LAN Connector

- CN Label: LAN1
 CN Type: RJ-45
 CN Location: See **Figure 3-20**
 CN Pinouts: See **Figure 3-21** and **Table 3-19**

The LAN connector connects to a local network.




Figure 3-21: LAN Connector

HYPER-BT

Pin	Description	Pin	Description
1	MDIA3-	5	MDIA2+
2	MDIA3+	6	MDIA1+
3	MDIA1-	7	MDIA0-
4	MDIA2-	8	MDIA0+

Table 3-19: LAN Pinouts

LED	Description	LED	Description
A	on: linked blinking: data is being sent/received	B	off: 10 Mb/s green: 100 Mb/s orange: 1000 Mb/s

Table 3-20: Connector LEDs

3.3.2 Power Connector

CN Label:	J1
CN Type:	12V DC IN
CN Location:	See Figure 3-20
CN Pinouts:	See Table 3-21

The power connector supports 12V DC power input.

Pin	Description	Pin	Description
1	VCC	2	GND
3	GND		

Table 3-21: Power Connector Pinouts

3.3.3 USB Connectors

CN Label:	CN2
CN Type:	USB 2.0 & USB 3.0 ports
CN Location:	See Figure 3-20
CN Pinouts:	See Table 3-21

The HYPER-BT has one external USB 2.0 port and one external USB 3.0 port. The USB connector can be connected to a USB device. The pinouts of USB 2.0 port & USB 3.0 connectors are shown below.

Pin	Description	Pin	Description
1	VCC_USB3_01	8	USB3P0_TXDN1
2	USB2P0_DM1_L	9	USB3P0_TXDP1
3	USB2P0_DP1_L	10	VCC_USB3_01
4	GND	11	DATA1_N
5	USB3P0_RXDN1	12	DATA1_P
6	USB3P0_RXDP1	13	GND
7	GND		

Table 3-22: USB 2.0 & USB 3.0 Port Pinouts

3.3.1 VGA Connector

- CN Label: VGA1
- CN Type: 15-pin female (VGA)
- CN Location: See **Figure 3-20**
- CN Pinouts: See **Figure 3-22** and **Table 3-23**

The VGA port connects to a monitor that accepts a standard VGA input.




Figure 3-22: VGA Connector

Pin	Description	Pin	Description
1	Red	2	Green
3	Blue	4	NC
5	GND	6	GND
7	GND	8	GND

HYPER-BT

Pin	Description	Pin	Description
9	VGAVCC	10	HOTPLUG
11	NC	12	DDCDAT
13	HSYNC	14	VSYNC
15	DDCCLK		

Table 3-23: VGA Connector Pinouts

Chapter

4

Installation

HYPER-BT

4.1 Anti-static Precautions



WARNING:

Failure to take ESD precautions during the installation of the HYPER-BT may result in permanent damage to the HYPER-BT and severe injury to the user.

Electrostatic discharge (ESD) can cause serious damage to electronic components, including the HYPER-BT. Dry climates are especially susceptible to ESD. It is therefore critical that whenever the HYPER-BT or any other electrical component is handled, the following anti-static precautions are strictly adhered to.

- ***Wear an anti-static wristband:*** Wearing a simple anti-static wristband can help to prevent ESD from damaging the board.
- ***Self-grounding:*** Before handling the board, touch any grounded conducting material. During the time the board is handled, frequently touch any conducting materials that are connected to the ground.
- ***Use an anti-static pad:*** When configuring the HYPER-BT, place it on an anti-static pad. This reduces the possibility of ESD damaging the HYPER-BT.
- ***Only handle the edges of the PCB:*** When handling the PCB, hold the PCB by the edges.

4.2 Installation Considerations



NOTE:

The following installation notices and installation considerations should be read and understood before installation. All installation notices must be strictly adhered to. Failing to adhere to these precautions may lead to severe damage and injury to the person performing the installation.

**WARNING:**

The installation instructions described in this manual should be carefully followed in order to prevent damage to the HYPER-BT, HYPER-BT components and injury to the user.

Before and during the installation please **DO** the following:

- Read the user manual:
 - The user manual provides a complete description of the HYPER-BT installation instructions and configuration options.
- Wear an electrostatic discharge cuff (ESD):
 - Electronic components are easily damaged by ESD. Wearing an ESD cuff removes ESD from the body and helps prevent ESD damage.
- Place the HYPER-BT on an antistatic pad:
 - When installing or configuring the motherboard, place it on an antistatic pad. This helps to prevent potential ESD damage.
- Turn all power to the HYPER-BT off:
 - When working with the HYPER-BT, make sure that it is disconnected from all power supplies and that no electricity is being fed into the system.

Before and during the installation of the HYPER-BT **DO NOT**:

- Remove any of the stickers on the PCB board. These stickers are required for warranty validation.
- Use the product before verifying all the cables and power connectors are properly connected.
- Allow screws to come in contact with the PCB circuit, connector pins, or its components.

HYPER-BT

4.3 SO-DIMM Installation

**WARNING:**

Using incorrectly specified SO-DIMM may cause permanently damage the HYPER-BT. Please make sure the purchased SO-DIMM complies with the memory specifications of the HYPER-BT. SO-DIMM specifications compliant with the HYPER-BT are listed in the specification table of Chapter 1.

To install an SO-DIMM, please follow the steps below and refer to Figure 4-1.




Figure 4-1: SO-DIMM Installation

- Step 1:** **Locate the SO-DIMM socket.** Place the board on an anti-static mat.
- Step 2:** **Align the SO-DIMM with the socket.** Align the notch on the memory with the notch on the memory socket.
- Step 3:** **Insert the SO-DIMM.** Push the memory in at a 20° angle. (See Figure 4-1)
- Step 4:** **Seat the SO-DIMM.** Gently push downwards and the arms clip into place. (See Figure 4-1)

4.4 Internal Peripheral Device Connections

This section outlines the installation of peripheral devices to the on-board connectors

4.4.1 Audio Kit Installation

The Audio Kit that came with the HYPER-BT connects to the audio connector on the HYPER-BT. The audio kit consists of three audio jacks. Mic-in connects to a microphone. Line-in provides a stereo line-level input to connect to the output of an audio device. Line-out, a stereo line-level output, connects to two amplified speakers. To install the audio kit, please refer to the steps below:

Step 1: **Locate the audio connector.** The location of the 10-pin audio connector is shown in **Chapter 3**.

Step 2: **Align pin 1.** Align pin 1 on the on-board connector with pin 1 on the audio kit connector. Pin 1 on the audio kit connector is indicated with a white dot. See Figure 4-2.




Figure 4-2: Audio Kit Cable Connection

HYPER-BT

Step 3: Connect the audio devices. Connect speakers to the line-out audio jack. Connect the output of an audio device to the line-in audio jack. Connect a microphone to the mic-in audio jack.

4.4.2 SATA Drive Connection

The HYPER-BT is shipped with a SATA drive cable. To connect the SATA drive to the connector, please follow the steps below.

Step 1: Locate the SATA connector and the SATA power connector. The locations of the connectors are shown in **Chapter 3**.

Step 2: Insert the cable connector. Insert the cable connector into the on-board SATA drive connector and the SATA power connector. See **Figure 4-3**.




Figure 4-3: SATA Drive Cable Connection

Step 3: Connect the cable to the SATA disk. Connect the connector on the other end of the cable to the connector at the back of the SATA drive. See **Figure 4-3**.

Step 4: To remove the SATA cable from the SATA connector, press the clip on the connector at the end of the cable.

4.4.3 Single RS-232 Cable

The single RS-232 cable consists of one serial port connector attached to a serial communications cable that is then attached to a D-sub 9 male connector. To install the single RS-232 cable, please follow the steps below.

Step 1: Locate the connector. The location of the RS-232 connector is shown in **Chapter 3**.

Step 2: Insert the cable connector. Insert the connector into the serial port box header. See Figure 4-4. A key on the front of the cable connectors ensures the connector can only be installed in one direction.




Figure 4-4: Single RS-232 Cable Installation

Step 3: Secure the bracket. The single RS-232 connector has two retention screws that must be secured to a chassis or bracket.

Step 4: Connect the serial device. Once the single RS-232 connector is connected to a chassis or bracket, a serial communications device can be connected to the system.

HYPER-BT

4.5 External Peripheral Interface Connection

The following external peripheral devices can be connected to the external peripheral interface connectors.

- RJ-45 LAN cable
- USB devices
- VGA monitor

To install these devices, connect the corresponding cable connector from the actual device to the corresponding HYPER-BT external peripheral interface connector making sure the pins are properly aligned.

4.5.1 LAN Connection

There is one external RJ-45 LAN connector on the external peripheral interface panel. The RJ-45 connector enables connection to an external network. To connect a LAN cable with an RJ-45 connector, please follow the instructions below.

Step 1: Locate the RJ-45 connector. The location of the LAN connector is shown in **Chapter 3**.

Step 2: Align the connector. Align the RJ-45 connector on the LAN cable with the RJ-45 connectors on the HYPER-BT. See **Figure 4-5**.




Figure 4-5: LAN Connection

Step 3: Insert the LAN cable RJ-45 connector. Once aligned, gently insert the LAN cable RJ-45 connector into the on-board RJ-45 connector.

4.5.2 USB Connection

The external USB Series "A" receptacle connectors provide easier and quicker access to external USB devices. Follow the steps below to connect USB devices to the HYPER-BT.

Step 1: Locate the USB Series "A" receptacle connectors. The locations of the USB Series "A" receptacle connectors are shown in **Chapter 3**.

Step 2: Insert a USB Series "A" plug. Insert the USB Series "A" plug of a device into the USB Series "A" receptacle on the external peripheral interface. See **Figure 4-6**.

HYPER-BT




Figure 4-6: USB Connector

4.5.3 VGA Monitor Connection

The HYPER-BT has a single female DB-15 connector on the external peripheral interface panel. The DB-15 connector is connected to a CRT or VGA monitor. To connect a monitor to the HYPER-BT, please follow the instructions below.

- Step 1: Locate the female DB-15 connector.** The location of the female DB-15 connector is shown in **Chapter 3**.
- Step 2: Align the VGA connector.** Align the male DB-15 connector on the VGA screen cable with the female DB-15 connector on the external peripheral interface.
- Step 3: Insert the VGA connector.** Once the connectors are properly aligned with the insert the male connector from the VGA screen into the female connector on the HYPER-BT. See **Figure 4-7**.




Figure 4-7: VGA Connector

Step 4: Secure the connector. Secure the DB-15 VGA connector from the VGA monitor to the external interface by tightening the two retention screws on either side of the connector.

Chapter

5

BIOS

5.1 Introduction

The BIOS is programmed onto the BIOS chip. The BIOS setup program allows changes to certain system settings. This chapter outlines the options that can be changed.



NOTE:

Some of the BIOS options may vary throughout the life cycle of the product and are subject to change without prior notice.

5.1.1 Starting Setup

The UEFI BIOS is activated when the computer is turned on. The setup program can be activated in one of two ways.

1. Press the **DELETE** or **F2** key as soon as the system is turned on or
2. Press the **DELETE** or **F2** key when the “**Press Del to enter SETUP**” message appears on the screen.

If the message disappears before the **DELETE** or **F2** key is pressed, restart the computer and try again.

5.1.2 Using Setup

Use the arrow keys to highlight items, press **ENTER** to select, use the PageUp and PageDown keys to change entries, press **F1** for help and press **ESC** to quit. Navigation keys are shown in.

Key	Function
Up arrow	Move to previous item
Down arrow	Move to next item
Left arrow	Move to the item on the left hand side
Right arrow	Move to the item on the right hand side
+	Increase the numeric value or make changes

HYPER-BT

Key	Function
-	Decrease the numeric value or make changes
F1 key	General help, only for Status Page Setup Menu and Option Page Setup Menu
F2 key	Load previous values.
F3 key	Load optimized defaults
F4 key	Save changes and Exit BIOS
Esc key	Main Menu – Quit and not save changes into CMOS Status Page Setup Menu and Option Page Setup Menu -- Exit current page and return to Main Menu

Table 5-1: BIOS Navigation Keys

5.1.3 Getting Help

When **F1** is pressed a small help window describing the appropriate keys to use and the possible selections for the highlighted item appears. To exit the Help Window press **ESC** or the **F1** key again.

5.1.4 Unable to Reboot after Configuration Changes

If the computer cannot boot after changes to the system configuration is made, CMOS defaults. Use the jumper described in Chapter 3.

5.1.5 BIOS Menu Bar

The **menu bar** on top of the BIOS screen has the following main items:

- Main – Changes the basic system configuration.
- Advanced – Changes the advanced system settings.
- Chipset – Changes the chipset settings.
- Boot – Changes the system boot configuration.
- Security – Sets User and Supervisor Passwords.
- Save & Exit – Selects exit options and loads default settings

The following sections completely describe the configuration options found in the menu items at the top of the BIOS screen and listed above.

5.2 Main

The **Main** BIOS menu (**BIOS Menu 1**) appears when the **BIOS Setup** program is entered. The **Main** menu gives an overview of the basic system information.

Aptio Setup Utility - Copyright (C) 2013 American Megatrends, Inc.		
Main	Advanced	Chipset Security Boot Save & Exit
BIOS Information		Set the Date. Use Tab to switch between Data elements.
BIOS Vendor	American Megatrends	
Core Version	5.009	
Compliancy	UEFI 2.3; PI 1.2	
Project Version	SAA7AR10.rom	
Build Date and Time	05/27/2014 11:46:33	
iWDD Vendor	iEi	
iWDD Version	SAA7ER10.bin	
CPU Configuration		
Microcode Patch	809	
BayTrail SoC	Unknown	
Memory Information		
Total Memory	4096 MB(LPDDR3)	-----
TXE Information		←→: Select Screen
Sec RC Version	00.05.00.00	↑ ↓: Select Item
TXE FW Version	01.00.02.1060	EnterSelect
System Date	[Fri 06/20/2014]	+/-: Change Opt.
System Time	[19:43:27]	F1: General Help
Access Level	Administrator	F2: Previous Values
		F3: Optimized Defaults
		F4: Save & Exit
		ESC: Exit
Version 2.16.1242. Copyright (C) 2013 American Megatrends, Inc.		

BIOS Menu 1: Main

The Main menu lists the following system details:

- BIOS Information
- iWDD Information
- CPU Configuration
- Memory Information
- TXE Information

HYPER-BT

The System Overview field also has two user configurable fields:

➔ System Date [xx/xx/xx]

Use the **System Date** option to set the system date. Manually enter the day, month and year.

➔ System Time [xx:xx:xx]

Use the **System Time** option to set the system time. Manually enter the hours, minutes and seconds.

5.3 Advanced

Use the **Advanced** menu (**BIOS Menu 2**) to configure the CPU and peripheral devices through the following sub-menus:



WARNING!

Setting the wrong values in the sections below may cause the system to malfunction. Make sure that the settings made are compatible with the hardware.

```

Aptio Setup Utility - Copyright (C) 2013 American Megatrends, Inc.
Main  Advanced  Chipset  Security  Boot  Save & Exit
-----
> ACPI Settings
> IT8528 Super IO Configuration
> Hardware Monitor
> RTC Wake Settings
> Serial Port Console Redirection
> CPU Configuration
> IDE Configuration
> USB Configuration


System ACPI Parameters.
-----
<=>: Select Screen
↑ ↓: Select Item
Enter>Select
F1  General Help
F2  Previous Values
F3  Optimized Defaults
F4  Save
ESC Exit

Version 2.16.1242. Copyright (C) 2013 American Megatrends, Inc.
    
```

BIOS Menu 2: Advanced

5.3.1 ACPI Settings

The **ACPI Settings** menu (**BIOS Menu 3**) configures the Advanced Configuration and Power Interface (ACPI) options.



BIOS Menu 3: ACPI Configuration

→ **ACPI Sleep State [S3 only (Suspend to RAM)]**

The fields in **ACPI Sleep State** option cannot be changed.

- **Suspend Disabled** Disable the suspend function.
- **S3 (Suspend to DEFAULT RAM)** The caches are flushed and the CPU is powered off. Power to the RAM is maintained. The computer returns slower to a working state, but more power is saved.

HYPER-BT

5.3.2 IT8528 Super IO Configuration

Use the **IT8528 Super IO Configuration** menu (**BIOS Menu 4**) to set or change the configurations for the serial ports.

```

Aptio Setup Utility - Copyright (C) 2013 American Megatrends, Inc.
  Advanced
IT8528 Super IO Configuration                               Set Parameters of Serial
                                                           Port 1 (COMA)
Super IO Chip                                             IT8528
> Serial Port 1 Configuration
                                                           -----
                                                           ←→: Select Screen
                                                           ↑ ↓: Select Item
                                                           EnterSelect
                                                           F1  General Help
                                                           F2  Previous Values
                                                           F3  Optimized
                                                           Defaults
                                                           F4  Save
                                                           ESC Exit
Version 2.16.1242. Copyright (C) 2013 American Megatrends, Inc.
    
```

BIOS Menu 4: Super IO Configuration

5.3.2.1 Serial Port 1 Configuration

Use the **Serial Port 1 Configuration** menu (**BIOS Menu 5**) to configure the serial port 1.

```

Aptio Setup Utility - Copyright (C) 2013 American Megatrends, Inc.
  Advanced
F81216 Serial Port 1 Configuration                       Enable or Disable Serial
                                                           Port (COM)
Serial Port                                             [Enabled]
Device Settings                                       IO=3F8h; IRQ=4
Change Settings                                       [Auto]
                                                           -----
                                                           ←→: Select Screen
                                                           ↑ ↓: Select Item
                                                           EnterSelect
                                                           F1  General Help
                                                           F2  Previous Values
                                                           F3  Optimized
                                                           Defaults
                                                           F4  Save
                                                           ESC Exit
Version 2.16.1242. Copyright (C) 2013 American Megatrends, Inc.
    
```

BIOS Menu 5: Serial Port 1 Configuration Menu

➔ Serial Port [Enabled]

Use the **Serial Port** option to enable or disable the serial port.

- ➔ **Disabled** Disable the serial port
- ➔ **Enabled** **DEFAULT** Enable the serial port

➔ Change Settings [Auto]

Use the **Change Settings** option to change the serial port IO port address and interrupt address.

- ➔ **Auto** **DEFAULT** The serial port IO port address and interrupt address are automatically detected.
- ➔ **IO=3F8h; IRQ=4** Serial Port I/O port address is 3F8h and the interrupt address is IRQ4
- ➔ **IO=3F8h; IRQ=3, 4,5,6,7,9,10,11,12** Serial Port I/O port address is 3F8h and the interrupt address is IRQ3,4,5,6,7,9,10,11,12
- ➔ **IO=2F8h; IRQ=3, 4,5,6,7,9,10,11,12** Serial Port I/O port address is 2F8h and the interrupt address is IRQ3,4,5,6,7,9,10,11,12
- ➔ **IO=3E8h; IRQ=3, 4,5,6,7,9,10,11,12** Serial Port I/O port address is 3E8h and the interrupt address is IRQ3,4,5,6,7,9,10,11,12
- ➔ **IO=2E8h; IRQ=3, 4,5,6,7,9,10,11,12** Serial Port I/O port address is 2E8h and the interrupt address is IRQ3,4,5,6,7,9,10,11,12

5.3.3 Hardware Monitor

The Hardware Monitor menu (**BIOS Menu 6**) contains the fan configuration submenus and displays operating temperature, fan speeds and system voltages.

HYPER-BT

```

Aptio Setup Utility - Copyright (C) 2013 American Megatrends, Inc.
Advanced
PC Health Status
> Smart Fan Function
CPU temperature           :+42 C
CPU Fan Speed            :N/A
SOC_VCC                  :+0.774 V
V1.0S                    :+0.996 V
V1.35S                   :+1.348 V
V1.35_DDR3               :+1.324 V
-----
<->: Select Screen
↑ ↓: Select Item
EnterSelect
+ - Change Opt.
F1  General Help
F2  Previous Values
F3  Optimized Defaults
F4  Save & Exit
ESC Exit
Version 2.16.1242. Copyright (C) 2013 American Megatrends, Inc.

```

BIOS Menu 6: Hardware Monitor


→ PC Health Status

The following system parameters and values are shown. The system parameters that are monitored are:

- System Temperatures:
 - CPU Temperature
- Fan Speed:
 - CPU Fan Speed
- Voltages:
 - SOC_VCC
 - V1.0S
 - V1.35S
 - V1.35_DDR3

5.3.3.1 Smart Fan Mode Configuration

Use the **Smart Fan Mode Configuration submenu (BIOS Menu 7)** to configure fan temperature and speed settings.



BIOS Menu 7: Smart Fan Mode Configuration

➔ CPU Smart Fan control [Auto PWM Mode]

Use the **CPU Smart Fan control** BIOS option to configure the CPU Smart Fan.

- ➔ **Full Mode** Fan is on all the time
- ➔ **Manual PWM Mode** The fan spins at the speed set in the manual PWM setting
- ➔ **Auto PWM Mode** **DEFAULT** The fan adjusts its speed using these settings:
 - Temperature of Off
 - Temperature of Start
 - Start PWM
 - Slope (Duty Cycle)

➔ Temperature of Off [75]



WARNING:

Setting this value too high may cause the fan to speed up only when

HYPER-BT

the CPU is at a very high temperature and therefore cause the system to be damaged.

The **Temperature of Off** option can only be set if the **CPU Smart Fan control** option is set to **Auto Mode**. If the CPU temperature is lower than **Temperature of Off**, the fan speed change to be lowest. To set a value, select the **Temperature of Off** option and enter a decimal number between 0 and 127. The temperature range is specified below.

- Minimum Value: 0°C
- Maximum Value: 127°C

→ Temperature of Start [80]



WARNING:

Setting this value too high may cause the fan to rotate at full speed only when the CPU is at a very high temperature and therefore cause the system to be damaged.

The **Temperature of Start** option can only be set if the **CPU Smart Fan control** option is set to **Auto Mode**. If the CPU temperature is between **Temperature of Off** and **Temperature of Start**, the fan speed change to be **Start PWM**. To set a value, select the **Temperature of Start** option and enter a decimal number between 0 and 127. The temperature range is specified below.

- Minimum Value: 0°C
- Maximum Value: 127°C

→ Start PWM [30]

The **Start PWM** option can only be set if the **CPU Smart Fan control** option is set to **Auto Mode**. Use the **Start PWM** option to set the PWM start value. To set a value, select the **Start PWM** option and enter a decimal number between 0 and 100. The temperature range is specified below.

- Minimum Value: 0
- Maximum Value: 100


➔ Slope (Duty Cycle) [4]

The **Slope (Duty Cycle)** option can only be set if the **CPU Smart Fan control** option is set to **Auto Mode**. Use the **Slope (Duty Cycle)** option to select the linear rate at which the PWM mode increases with respect to an increase in temperature. A list of available options is shown below:

- 0
- 1
- 2
- 4
- 8
- 16

5.3.4 RTC Wake Settings

The **RTC Wake Settings** menu (**BIOS Menu 8**) configures RTC wake event.



BIOS Menu 8: RTC Wake Settings

HYPER-BT

→ Wake system with Fixed Time [Disabled]

Use the **Wake system with Fixed Time** option to enable or disable the system wake on alarm event.

→ **Disabled** **DEFAULT** The real time clock (RTC) cannot generate a wake event

→ **Enabled** If selected, the **Wake up every day** option appears allowing you to enable to disable the system to wake every day at the specified time. Besides, the following options appear with values that can be selected:

Wake up date

Wake up hour


Wake up minute

Wake up second

After setting the alarm, the computer turns itself on from a suspend state when the alarm goes off.

5.3.5 Serial Port Console Redirection

The **Serial Port Console Redirection** menu (**BIOS Menu 9**) allows the console redirection options to be configured. Console redirection allows users to maintain a system remotely by re-directing keyboard input and text output through the serial port.



BIOS Menu 9: Serial Port Console Redirection

➔ Console Redirection [Disabled]


Use **Console Redirection** option to enable or disable the console redirection function.

- ➔ **Disabled** **DEFAULT** Disabled the console redirection function
- ➔ **Enabled** Enabled the console redirection function

5.3.5.1 Console Redirection Settings

The **Console Redirection Settings** menu (**BIOS Menu 10**) allows the console redirection options to be configured. The option is active when Console Redirection option is enabled.

HYPER-BT



BIOS Menu 10: Console Redirection Settings

→ Terminal Type [ANSI]

Use the **Terminal Type** option to specify the remote terminal type.

- **VT100** The target terminal type is VT100
- **VT100+** The target terminal type is VT100+
- **VT-UTF8** The target terminal type is VT-UTF8
- **ANSI** **DEFAULT** The target terminal type is ANSI

→ Bits per second [115200]

Use the **Bits per second** option to specify the serial port transmission speed. The speed must match the other side. Long or noisy lines may require lower speeds.

- **9600** Sets the serial port transmission speed at 9600.
- **19200** Sets the serial port transmission speed at 19200.

- **38400** Sets the serial port transmission speed at 38400.
- **57600** Sets the serial port transmission speed at 57600.
- **115200** **DEFAULT** Sets the serial port transmission speed at 115200.

→ Data Bits [8]

Use the **Data Bits** option to specify the number of data bits.

- **7** Sets the data bits at 7.
- **8** **DEFAULT** Sets the data bits at 8.

→ Parity [None]

Use the **Parity** option to specify the parity bit that can be sent with the data bits for detecting the transmission errors.

- **None** **DEFAULT** No parity bit is sent with the data bits.
- **Even** The parity bit is 0 if the number of ones in the data bits is even.
- **Odd** The parity bit is 0 if the number of ones in the data bits is odd.
- **Mark** The parity bit is always 1. This option does not provide error detection.
- **Space** The parity bit is always 0. This option does not provide error detection.

→ Stop Bits [1]

Use the **Stop Bits** option to specify the number of stop bits used to indicate the end of a serial data packet. Communication with slow devices may require more than 1 stop bit.

- **1** **DEFAULT** Sets the number of stop bits at 1.
- **2** Sets the number of stop bits at 2.

HYPER-BT

5.3.6 CPU Configuration

Use the **CPU Configuration** menu (**BIOS Menu 11**) to view detailed CPU specifications and configure the CPU.

```

Aprio Setup Utility - Copyright (C) 2013 American Megatrends, Inc.
  Advanced
CPU Configuration
Intel(R) Celeron(R) CPU N2807 @ 1.58GHz
CPU Signature                30678
Microcode Patch              809
Max CPU Speed                 1580 MHz
Min CPU Speed                 500 MHz
Processor Cores               2
Intel HT Technology           Not Supported
Intel VT-x Technology         Supported

L1 Data Cache                 24 KB x 2
L1 Code Cache                 32 KB x 2
L2 Cache                      1024 KB x 1
L3 Cache                      Not Present
CPU Speed                     1584 MHz
64-bit                        Supported

Intel Virtualization Technology [Enabled]
EIST                           [Enabled]

When enabled, a VMM can utilize the additional hardware capabilities provided by Vanderpool Technology.

-----
<->: Select Screen
^ v: Select Item
Enter>Select
F1   General Help
F2   Previous Values
F3   Optimized
Defaults
F4   Save
ESC  Exit

Version 2.16.1242. Copyright (C) 2013 American Megatrends, Inc.
  
```

BIOS Menu 11: CPU Configuration

→ Intel® Virtualization Technology [Disabled]

Use the **Intel® Virtualization Technology** option to enable or disable virtualization on the system. When combined with third party software, Intel Virtualization technology allows several OSs to run on the same system at the same time.

→ **Disabled** **DEFAULT** Disables Intel Virtualization Technology.

→ **Enabled** Enables Intel Virtualization Technology.


→ EIST [Enabled]

Use the **EIST** option to enable or disable the Intel Speed Step Technology.

- ➔ **Disabled** Disables the Intel Speed Step Technology.
- ➔ **Enabled DEFAULT** Enables the Intel Speed Step Technology.

5.3.7 IDE Configuration

Use the **IDE Configuration** menu (**BIOS Menu 12**) to change and/or set the configuration of the SATA devices installed in the system.



BIOS Menu 12: IDE Configuration

- ➔ SATA Mode [ACHI Mode]

Use the **SATA Mode** option to configure SATA devices as normal IDE devices.

- ➔ **IDE Mode** Configures SATA devices as normal IDE device.
- ➔ **ACHI Mode DEFAULT** Configures SATA devices as AHCI device.

- ➔ Serial-ATA Port 0 [Enabled]

Use the **Serial-ATA Port 0** option to enable or disable the SATA device.

- ➔ **Disabled** Disables the SATA device.
- ➔ **Enabled DEFAULT** Enables the SATA device.

HYPER-BT


➔ SATA Port 0 HotPlug [Disabled]

Use the **Serial-ATA Port 0 HotPlug** option to enable or disable the SATA device hot plug.

- ➔ **Disabled** Disables the SATA device hot plug.
- ➔ **Enabled** **DEFAULT** Enables the SATA device hot plug

5.3.8 USB Configuration

Use the **USB Configuration** menu (**BIOS Menu 13**) to read USB configuration information and configure the USB settings.



BIOS Menu 13: USB Configuration

➔ USB Devices

The **USB Devices Enabled** field lists the USB devices that are enabled on the system

➔ Legacy USB Support [Enabled]

Use the **Legacy USB Support** BIOS option to enable USB mouse and USB keyboard support. Normally if this option is not enabled, any attached USB mouse or USB keyboard

does not become available until a USB compatible operating system is fully booted with all USB drivers loaded. When this option is enabled, any attached USB mouse or USB keyboard can control the system even when there is no USB driver loaded onto the system.

- ➔ **Enabled** **DEFAULT** Legacy USB support enabled
- ➔ **Disabled** Legacy USB support disabled
- ➔ **Auto** Legacy USB support disabled if no USB devices are connected

5.4 Chipset

Use the **Chipset** menu (**BIOS Menu 14**) to access the Northbridge and Southbridge configuration menus



WARNING!

Setting the wrong values for the Chipset BIOS selections in the Chipset BIOS menu may cause the system to malfunction.

```

Aptio Setup Utility - Copyright (C) 2013 American Megatrends, Inc.
Main   Advanced  Chipset  Security  Boot   Save & Exit
-----
> North Bridge
> South Bridge

North Bridge Parameters
-----
<=>: Select Screen
↑↓: Select Item
Enter>Select
+/-: Change Opt.
F1   General Help
F2   Previous Values
F3   Optimized Defaults
F4   Save & Exit
ESC  Exit

Version 2.16.1242. Copyright (C) 2013 American Megatrends, Inc.
    
```

BIOS Menu 14: Chipset

HYPER-BT

5.4.1 North Bridge Configuration

Use the **North Bridge Configuration** menu (**BIOS Menu 15**) to configure the Intel IGD settings.

```

Aptio Setup Utility - Copyright (C) 2013 American Megatrends, Inc.
Chipset
> Intel IGD Configuration
Memory Information
Total Memory          4096 MB(LPDDR3)
Memory Slot0         4096 MB(LPDDR3)
Configure Intel IGD Settings.
-----
<->: Select Screen
↑ ↓: Select Item
EnterSelect
+/-: Change Opt.
F1:  General Help
F2:  Previous Values
F3:  Optimized Defaults
F4:  Save & Exit
ESC: Exit
Version 2.16.1242. Copyright (C) 2013 American Megatrends, Inc.

```


BIOS Menu 15: Northbridge Chipset Configuration

→ Memory Information

The **Memory Information** lists a brief summary of the on-board memory. The fields in **Memory Information** cannot be changed.

5.4.1.1 Intel IGD Configuration

Use the **Intel IGD Configuration** menu (**BIOS Menu 16**) to configure the video device connected to the system.



BIOS Menu 16: Integrated Graphics

→ DVMT Pre-Allocated [256MB]

Use the **DVMT Pre-Allocated** option to set the amount of system memory allocated to the integrated graphics processor when the system boots. The system memory allocated can then only be used as graphics memory, and is no longer available to applications or the operating system. Configuration options are listed below:

- 64M
- 128M
- 256M **Default**
- 512M

→ DVMT Total Gfx Mem [MAX]

Use the **DVMT Total Gfx Mem** option to select DVMT5.0 total graphic memory size used by the internal graphic device. The following options are available:

- 128M
- 256M
- MAX **Default**

HYPER-BT

→ Primary IGFX Boot Display [VBIOS Default]

Use the **Primary IGFX Boot Display** option to select the display device used by the system when it boots. For dual display support, select “VBIOS Deafult.” Configuration options are listed below.

- VBIOS Default **DEFAULT**
- CRT
- DP Port

5.4.2 Southbridge Configuration

Use the **Southbridge Configuration** menu (**BIOS Menu 17**) to configure the Southbridge chipset.

```

Aptio Setup Utility - Copyright (C) 2013 American Megatrends, Inc.
Chipset
Auto Power Button Status      [Enabled(AT)]      EUP Disable/Enable.
Power Saving(EUP)             [Disabled]
Audio Configuration
Audio Controller              [Enabled]
-----
←→: Select Screen
↑ ↓: Select Item
EnterSelect
+/-: Change Opt.
F1: General Help
F2: Previous Values
F3: Optimized Defaults
F4: Save & Exit
ESC: Exit
Version 2.16.1242. Copyright (C) 2013 American Megatrends, Inc.
    
```

BIOS Menu 17: Southbridge Chipset Configuration

→ Power Saving (EUP) [Disabled]

Use the **Power Saving (EUP)** option to enable or disable the power saving function.

- **Disabled** **DEFAULT** Power saving function is disabled.
- **Enabled** Power saving function is enabled. It will reduce power consumption when the system is off.


➔ Audio Controller [Enabled]

Use the **Audio Controller** option to enable or disable the High Definition Audio controller.

- ➔ **Disabled** The onboard High Definition Audio controller is disabled
- ➔ **Enabled DEFAULT** The onboard High Definition Audio controller is detected automatically and enabled

5.5 Security

Use the **Security** menu (**BIOS Menu 18**) to set system and user passwords.



BIOS Menu 18: Security

➔ Administrator Password

Use the **Administrator Password** to set or change a administrator password.


➔ User Password

Use the **User Password** to set or change a user password.

HYPER-BT

5.6 Boot

Use the **Boot** menu (**BIOS Menu 19**) to configure system boot options.



BIOS Menu 19: Boot

→ Bootup NumLock State [On]

Use the **Bootup NumLock State** BIOS option to specify if the number lock setting must be modified during boot up.

→ **On** **DEFAULT** Allows the Number Lock on the keyboard to be enabled automatically when the computer system boots up. This allows the immediate use of the 10-key numeric keypad located on the right side of the keyboard. To confirm this, the Number Lock LED light on the keyboard is lit.

→ **Off** Does not enable the keyboard Number Lock automatically. To use the 10-keys on the keyboard, press the Number Lock key located on the upper left-hand corner of the 10-key pad. The Number Lock LED on the keyboard lights up when the Number Lock is engaged.

→ Quiet Boot [Enabled]

Use the **Quiet Boot** BIOS option to select the screen display when the system boots.

- **Disabled** Normal POST messages displayed
- **Enabled** **DEFAULT** OEM Logo displayed instead of POST messages

→ Option ROM Messages [Force BIOS]

Use the **Option ROM Messages** option to set the Option ROM display mode.

- **Force BIOS** **DEFAULT** Sets display mode to force BIOS.
- **Keep Current** Sets display mode to current.

→ UEFI Boot [Disabled]

Use the **UEFI Boot** option to enable or disable to boot from the UEFI devices.

- **Auto** If the first boot HDD is GPT then enable UEFI boot options, otherwise disable,
- **Enabled** Boot from UEFI devices is enabled.
- **Disabled** **DEFAULT** Boot from UEFI devices is disabled.

→ Launch PXE OpROM [Disabled]

Use the **Launch PXE OpROM** option to enable or disable boot option for legacy network devices.

- **Disabled** **DEFAULT** Ignore all PXE Option ROMs
- **Enabled** Load PXE Option ROMs.

HYPER-BT

→ Boot Option Priority

Use the **Boot Option Priority** function to set the system boot sequence from the available devices. The drive sequence also depends on the boot sequence in the individual device section.

5.7 Exit

Use the **Exit** menu (**BIOS Menu 20**) to load default BIOS values, optimal failsafe values and to save configuration changes.

```

Aptio Setup Utility - Copyright (C) 2013 American Megatrends, Inc.
Main   Advanced  Chipset  Security  Boot   Save & Exit
-----
Save Changes and Reset
Discard Changes and Reset

Restore Defaults
Save as User Defaults
Restore User Defaults

Reset the system after
saving the changes.

-----
<=>: Select Screen
↑ ↓: Select Item
Enter>Select
F1   General Help
F2   Previous Values
F3   Optimized
Defaults
F4   Save
ESC  Exit

Version 2.16.1242. Copyright (C) 2013 American Megatrends, Inc.

```

BIOS Menu 20:Exit

→ Save Changes and Reset

Use the **Save Changes and Reset** option to save the changes made to the BIOS options and to exit the BIOS configuration setup program.

→ Discard Changes and Reset

Use the **Discard Changes and Reset** option to exit the system without saving the changes made to the BIOS configuration setup program.

→ Restore Defaults

Use the **Restore Defaults** option to load the optimal default values for each of the parameters on the Setup menus. **F3 key can be used for this operation.**

→ Save as User Defaults

Use the **Save as User Defaults** option to save the changes done so far as user defaults.

→ Restore User Defaults

Use the **Restore User Defaults** option to restore the user defaults to all the setup options.

Appendix

A

Regulatory Compliance

DECLARATION OF CONFORMITY



This equipment has been tested and found to comply with specifications for CE marking. If the user modifies and/or installs other devices in the equipment, the CE conformity declaration may no longer apply.

FCC WARNING



This equipment complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- This device may not cause harmful interference, and
- This device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

Appendix

B


Product Disposal

**CAUTION:**

Risk of explosion if battery is replaced by an incorrect type. Only certified engineers should replace the on-board battery.

Dispose of used batteries according to instructions and local regulations.

- Outside the European Union – If you wish to dispose of used electrical and electronic products outside the European Union, please contact your local authority so as to comply with the correct disposal method.
- Within the European Union – The device that produces less waste and is easier to recycle is classified as electronic device in terms of the European Directive 2012/19/EU (WEEE), and must not be disposed of as domestic garbage.



EU-wide legislation, as implemented in each Member State, requires that waste electrical and electronic products carrying the mark (left) must be disposed of separately from normal household waste. This includes monitors and electrical accessories, such as signal cables or power cords. When you need to dispose of your device, please follow the guidance of your local authority, or ask the shop where you purchased the product. The mark on electrical and electronic products only applies to the current European Union Member States.

Please follow the national guidelines for electrical and electronic product disposal.

Appendix

C

BIOS Menu Options

- ➔ System Date [xx/xx/xx]51
- ➔ System Time [xx:xx:xx]51
- ➔ ACPI Sleep State [S3 only (Suspend to RAM)]52
- ➔ Serial Port [Enabled].....54
- ➔ Change Settings [Auto]54
- ➔ PC Health Status55
- ➔ CPU Smart Fan control [Auto PWM Mode].....56
- ➔ Temperature of Off [75]56
- ➔ Temperature of Start [80]57
- ➔ Start PWM [30].....57
- ➔ Slope (Duty Cycle) [4].....58
- ➔ Wake system with Fixed Time [Disabled].....59
- ➔ Console Redirection [Disabled].....60
- ➔ Terminal Type [ANSI].....61
- ➔ Bits per second [115200].....61
- ➔ Data Bits [8]62
- ➔ Parity [None].....62
- ➔ Stop Bits [1].....62
- ➔ Intel® Virtualization Technology [Disabled].....63
- ➔ EIST [Enabled].....63
- ➔ SATA Mode [ACHI Mode]64
- ➔ Serial-ATA Port 0 [Enabled].....64
- ➔ SATA Port 0 HotPlug [Disabled].....65
- ➔ USB Devices65
- ➔ Legacy USB Support [Enabled].....65
- ➔ Memory Information67
- ➔ DVMT Pre-Allocated [256MB].....68
- ➔ DVMT Total Gfx Mem [MAX].....68
- ➔ Primary IGFX Boot Display [VBIOS Default]69
- ➔ Power Saving (EUP) [Disabled]69
- ➔ Audio Controller [Enabled]70
- ➔ Administrator Password70
- ➔ User Password70
- ➔ Bootup NumLock State [On].....71

HYPER-BT

→ Quiet Boot [Enabled]	72
→ Option ROM Messages [Force BIOS].....	72
→ UEFI Boot [Disabled]	72
→ Launch PXE OpROM [Disabled]	72
→ Boot Option Priority.....	73
→ Save Changes and Reset	73
→ Discard Changes and Reset	73
→ Restore Defaults	74
→ Save as User Defaults	74
→ Restore User Defaults	74

Appendix

D

Terminology

HYPER-BT

AC '97	Audio Codec 97 (AC'97) refers to a codec standard developed by Intel® in 1997.
ACPI	Advanced Configuration and Power Interface (ACPI) is an OS-directed configuration, power management, and thermal management interface.
AHCI	Advanced Host Controller Interface (AHCI) is a SATA Host controller register-level interface.
ATA	The Advanced Technology Attachment (ATA) interface connects storage devices including hard disks and CD-ROM drives to a computer.
APM	The Advanced Power Management (APM) application program interface (API) enables the inclusion of power management in the BIOS.
ARMD	An ATAPI Removable Media Device (ARMD) is any ATAPI device that supports removable media, besides CD and DVD drives.
ASKIR	Amplitude Shift Keyed Infrared (ASKIR) is a form of modulation that represents a digital signal by varying the amplitude (“volume”) of the signal. A low amplitude signal represents a binary 0, while a high amplitude signal represents a binary 1.
BIOS	The Basic Input/Output System (BIOS) is firmware that is first run when the computer is turned on and can be configured by the end user
CODEC	The Compressor-Decompressor (CODEC) encodes and decodes digital audio data on the system.
CMOS	Complimentary metal-oxide-conductor is a type of integrated circuit used in chips like static RAM and microprocessors.
COM	COM is used to refer to serial ports. Serial ports offer serial communication to expansion devices. The serial port on a personal

	computer is usually a male DE-9 connector.
DAC	The Digital-to-Analog Converter (DAC) converts digital signals to analog signals.
DDR	Double Data Rate refers to a data bus transferring data on both the rising and falling edges of the clock signal.
DMA	Direct Memory Access (DMA) enables some peripheral devices to bypass the system processor and communicate directly with the system memory.
DIMM	Dual Inline Memory Modules are a type of RAM that offer a 64-bit data bus and have separate electrical contacts on each side of the module.
EHCI	The Enhanced Host Controller Interface (EHCI) specification is a register-level interface description for USB 2.0 Host Controllers.
GbE	Gigabit Ethernet (GbE) is an Ethernet version that transfers data at 1.0 Gbps and complies with the IEEE 802.3-2005 standard.
GPIO	General purpose input
IrDA	Infrared Data Association (IrDA) specify infrared data transmission protocols used to enable electronic devices to wirelessly communicate with each other.
L1 Cache	The Level 1 Cache (L1 Cache) is a small memory cache built into the system processor.
L2 Cache	The Level 2 Cache (L2 Cache) is an external processor memory cache.
LVDS	Low-voltage differential signaling (LVDS) is a dual-wire, high-speed differential electrical signaling system commonly used to connect LCD displays to a computer.
MAC	The Media Access Control (MAC) protocol enables several terminals or network nodes to communicate in a LAN, or other multipoint networks.

HYPER-BT

PCIe	PCI Express (PCIe) is a communications bus that uses dual data lines for full-duplex (two-way) serial (point-to-point) communications between the SBC components and/or expansion cards and the SBC chipsets. Each line has a 2.5 Gbps data transmission rate and a 250 MBps sustained data transfer rate.
POST	The Power-on Self Test (POST) is the pre-boot actions the system performs when the system is turned-on.
QVGA	Quarter Video Graphics Array (QVGA) refers to a display with a resolution of 320 x 240 pixels.
RAM	Random Access Memory (RAM) is a form of storage used in computer. RAM is volatile memory, so it loses its data when power is lost. RAM has very fast data transfer rates compared to other storage like hard drives.
SATA	Serial ATA (SATA) is a serial communications bus designed for data transfers between storage devices and the computer chipsets. The SATA bus has transfer speeds up to 1.5 Gbps and the SATA 3Gb/s bus has data transfer speeds of up to 3.0 Gbps.
S.M.A.R.T	Self Monitoring Analysis and Reporting Technology (S.M.A.R.T) refers to automatic status checking technology implemented on hard disk drives.
UART	Universal Asynchronous Receiver-transmitter (UART) is responsible for asynchronous communications on the system and manages the system's serial communication (COM) ports.
UHCI	The Universal Host Controller Interface (UHCI) specification is a register-level interface description for USB 1.1 Host Controllers.
USB	The Universal Serial Bus (USB) is an external bus standard for interfacing devices. USB 1.1 supports 12Mbps data transfer rates, while

USB 2.0 supports 480Mbps data transfer rates.

VGA

The Video Graphics Array (VGA) is a graphics display system developed by IBM.

Appendix

E

Hazardous Materials Disclosure

The details provided in this appendix are to ensure that the product is compliant with the Peoples Republic of China (China) RoHS standards. The table below acknowledges the presences of small quantities of certain materials in the product, and is applicable to China RoHS only.

A label will be placed on each product to indicate the estimated “Environmentally Friendly Use Period” (EFUP). This is an estimate of the number of years that these substances would “not leak out or undergo abrupt change.” This product may contain replaceable sub-assemblies/components which have a shorter EFUP such as batteries and lamps. These components will be separately marked.

Please refer to the following table.

Part Name	Toxic or Hazardous Substances and Elements					
	Lead (Pb)	Mercury (Hg)	Cadmium (Cd)	Hexavalent Chromium (CR(VI))	Polybrominated Biphenyls (PBB)	Polybrominated Diphenyl Ethers (PBDE)
Housing	O	O	O	O	O	O
Display	O	O	O	O	O	O
Printed Circuit Board	O	O	O	O	O	O
Metal Fasteners	O	O	O	O	O	O
Cable Assembly	O	O	O	O	O	O
Fan Assembly	O	O	O	O	O	O
Power Supply Assemblies	O	O	O	O	O	O
Battery	O	O	O	O	O	O

O: This toxic or hazardous substance is contained in all of the homogeneous materials for the part is below the limit requirement in SJ/T11363-2006 (now replaced by GB/T 26572-2011).

X: This toxic or hazardous substance is contained in at least one of the homogeneous materials for this part is above the limit requirement in SJ/T11363-2006 (now replaced by GB/T 26572-2011).

HYPER-BT

此附件旨在确保本产品符合中国 RoHS 标准。以下表格标示此产品中某有毒物质的含量符合中国 RoHS 标准规定的限量要求。

本产品上会附有“环境友好使用期限”的标签，此期限是估算这些物质“不会有泄漏或突变”的年限。本产品可能包含有较短的环境友好使用期限的可替换元件，像是电池或灯管，这些元件将会单独标示出来。

部件名称	有毒有害物质或元素					
	铅 (Pb)	汞 (Hg)	镉 (Cd)	六价铬 (CR(VI))	多溴联苯 (PBB)	多溴二苯 醚 (PBDE)
壳体	○	○	○	○	○	○
显示	○	○	○	○	○	○
印刷电路板	○	○	○	○	○	○
金属螺帽	○	○	○	○	○	○
电缆组装	○	○	○	○	○	○
风扇组装	○	○	○	○	○	○
电力供应组装	○	○	○	○	○	○
电池	○	○	○	○	○	○

○: 表示该有毒有害物质在该部件所有物质材料中的含量均在 SJ/T 11363-2006 (现由 GB/T 26572-2011 取代) 标准规定的限量要求以下。

X: 表示该有毒有害物质至少在该部件的某一均质材料中的含量超出 SJ/T 11363-2006 (现由 GB/T 26572-2011 取代) 标准规定的限量要求。