



# LP-5231 Series Quick Start


v1.6, August 2018

## What's in the box?

The package includes the following items:



**LP-5231 module**



**CD**



**CA-0910 Cable**




**Quick start**



**Pin Terminal \* 16**



**Screw Driver**



**M3x6L Screw \* 4**  
**44 mm DIN-Rail Clip \* 1**  
(LP-5231PM-3GWA)  
(LP-5231M-4GE/4GC)  
(LP-5231M)



**GSM/GPRS External Antenna(ANT-421-04)**  
(LP-5231PM-3GWA)  
(LP-5231PM-4GE/4GC)



**GPS Active External Antenna(ANT-115-03)**  
(LP-5231PM-3GWA)  
(LP-5231PM-4GE/4GC)

## Technical Support

If you are new to LP-5231 Series, please read the “Chapter 5. System Settings” of the User Manual for detailed information.

CD:\LinPAC\Napdos\lp-5000\lp-52xx\lp-5231\User\_Manual

[ftp://ftp.icpdas.com/pub/cd/linpac/napdos/lp-5000/lp-52xx/lp-5231/user\\_manual](ftp://ftp.icpdas.com/pub/cd/linpac/napdos/lp-5000/lp-52xx/lp-5231/user_manual)

Technical support: [service@icpdas.com](mailto:service@icpdas.com)



# LP-5231 系列快速上手指南


v1.6, August 2018

## 產品內容?

產品包含以下配件:



LP-5231 系列模組



軟體光碟



CA-0910 纜線




快速上手指南



歐式壓著端子 \* 16



螺絲起子



M3x6L 螺絲 \* 4



GSM/GPRS 外部天線



GPS Active 外部天線

DIN-Rail 固定架 \* 1

(LP-5231PM-3GWA)  
(LP-5231M-4GE/4GC)  
(LP-5231M)

(ANT-421-04)

(LP-5231PM-3GWA)  
(LP-5231PM-4GE/4GC)

(ANT-115-03)

(LP-5231PM-3GWA)  
(LP-5231PM-4GE/4GC)

## Technical Support

請參閱 LP-5231 系列使用手冊第 5 章「System Settings」了解入門資訊。

CD:\LinPAC\Napdos\lp-5000\lp-52xx\lp-5231\User\_Manual

[ftp://ftp.icpdas.com/pub/cd/linpac/napdos/lp-5000/lp-52xx/lp-5231/user\\_manual](ftp://ftp.icpdas.com/pub/cd/linpac/napdos/lp-5000/lp-52xx/lp-5231/user_manual)

Technical support: [service@icpdas.com](mailto:service@icpdas.com)