



Pin Assignment	Terminal No.	Pin Assignment
Ext.PWR	19	37
Ext.GND	18	36
Ext.GND	17	35
DI_15	16	34
DI_14	15	33
DI_13	14	32
DI_12	13	31
DI_11	12	30
DI_10	11	29
DI_9	10	28
DI_8	09	27
DI_7	08	26
DI_6	07	25
DI_5	06	24
DI_4	05	23
DI_3	04	22
DI_2	03	21
DI_1	02	20
DI_0	01	

37-pin Male D-Sub Connector