



Terminal No.	Pin Assignment
01	IO0
02	IO1
03	IO2
04	IO3
05	IO4
06	IO5
07	IO6
08	IO7
09	IO8
10	IO9
11	IO10
12	IO11
13	IO12
14	IO13
15	IO14
16	IO15
17	EXTGND
18	EXTGND
19	EXTPWR
20	EXTPWR