

## Welcome to SYSGuard 7001 Main Unit Quick Installation Guide

### INTRODUCTION

#### Box Contents

- SYSGuard 7001 Main Unit
- 1 Assembly Screws
- Mounting Kit
- Power Cable



#### **Before Installation!**

*Make sure your device is properly mounted and ready to operate safely.*

#### Step 1

Plug-in Power Cable to SYSGuard 7001 Main Unit. Wait for the "**READY**" LED. When the LED comes online SYSGuard 7001 Main Unit is ready to run.



#### Step 2


Main unit is equipped with default IP address (**192.168.1.234**). For the first access to the device a PC must be used to access the main unit and devices should be connected to the same network.

Your PC should have a static IP in order to access SYSGuard 7001. You can carry out these settings in TCP/IP Settings sections of Local Area Network Connection options.

#### Step 3


Write **192.168.1.234** on the address bar of your browser (for instance Internet Explorer) and press Enter button.

Homepage of the SYSGuard7001 Main Unit is as follows: Default user name is "**admin**" and password is "**123456**".




### Step 4

Before connecting the sensor to the system, it is necessary to have SYSGuard 7001 Main Unit gone into Sensor Assignment Mode. Enter "**Sensor Settings**" section in WebPack interface. Click on "**Add New Sensor**", SYSGuard 7001 Main Unit will go Sensor Assignment Mode.



### Water Detect Cable and Smoke Detector Connection Diagrams



## LIMITED PRODUCT WARRANTY

All Exagate products are covered with 2 years limited guarantee from the date of original purchase. (Warranty duration may change depending on your country) Your sales or delivery receipt, showing the date of purchase of product is your proof of purchase. Exagate is obliged to repair or replace the defective hardware (or any part of it's) with no charge to owner.

### Conditions Void of Warranty

- Damages on unit, cable or screen.
- Defections due to electrical wiring and/or city network.
- Interference to unit by non-authorized staff.
- Any problems caused by act of nature.
- Misusage of unit stated by the user manual.
- Removal or destruction of serial number, warranty labels.
- Any kind of modifications on unit.

#### Head Office

A: Yeşilce Mh. Doğa Sk. Kökten Plaza No:6 Kat:2 34418 Kağıthane -  
İstanbul T: +90 212 275 73 22 F: +90 212 275 73 66  
E: [info@exagate.com](mailto:info@exagate.com)

#### Support

[support@exagate.com](mailto:support@exagate.com)

